



Ultimate Nano Coat V3 – Application instructions



Before UNC V3 application, please make sure the bare metal surface is polished and cleaned with IPA (Isopropanol).



We recommend using polishing compounds with minimum or no oils in content. Polishing compounds with waxes and high oil content should be avoided.



Important:

It's very important to have good lighting in the place of application! In dim light you might not spot smears left behind and removing them later will be a lot more difficult.



Also, good ventilation will be necessary for health and safety regulations.



Please make sure you have the following before UNC v2 application:

1. IPA.
2. Ultimate Nano Coat v3.
3. Applicator sponge.
4. Microfiber towels.

UNC v3 Application:

Once again make sure the surface is cleaned with IPA before coating application. Clean the surface thoroughly with a fresh microfiber towel and make sure there are no visible marks on the metal surface before commencing the coating.

1. Open the UNC v3 bottle and put the applicator sponge on top and shake it once. Move the sponge a bit and shake it again. Do it for 3-4 times till the sponge is a bit wet (not soaked!).

2. Put the sponge on the surface and apply the coating with short and quick movements.

Don't do circular movements. Keep applying till the whole area is covered.

3. At temperatures of less than 25c leave the coating for less than 3 minutes before removal. At higher temperatures remove the coating almost immediately after applying.

4. Remove the coating with a microfiber towel cloth till smear free. We recommend using 2 towels/cloths for excess coating removal.

5. For extra durability we recommend applying a second layer. Second layer is to be applied 2-3 hours after the first one. The hotter, the shorter the interval is.



Mercedes-Benz





Tips:

1. Always use new microfiber towels.
2. The coating could crystallize around the bottle necks, so take extra care when opening bottles for the first time and close the cap when the coating bottle is not in use.
3. Attention: once the sponge is dried, it couldn't be re-used.
4. Don't work outside. Use a shady, protected and ventilated environment.
5. Recommended consumption: 7.5 ml per sqm for a single layer or 10 ml. per sqm as a double.

UNC v3 application on a muffler

